Telium Series				
ingenico beyond RETAIL				
Quick Reference Guide				
Credit Card Sale (Swiped)	Credit Card Sale (Key Entered)	Credit Card Return	Guide to Keys	
Swipe/Tap Card* or press > Select 1 - CREDIT Enter the Sale amount and press > If 1 key was pressed, Swipe/Tap Card* > Additional optional prompts may appear depending on terminal configuration.	Press Press 1 > Select 1 - CREDIT Enter the Sale amount and press O Manually enter the card number and press O Enter the expiration date and press O Enter the expiration date and press O > CVC Code. + O > Card present? Choose Yes or No. > Address +	Press 2 > Enter the password and press 0 > Select 1 - CREDIT 0 Enter the Return amount and press 0 Swipe/Tap* or Key Card and press 0 > Enter the expiration date and press 0	F4 Use to Set Language Image ENTER Key (Green) Note: ENTER Key at Idle will also access a Main Menu of functions. Image CLEAR Key (Yellow) Image CLEAR Key (Yellow) Image CANCEL Key (Red) Image FUNCTION Key Image Function Key Use F key to access the System Manager Menu and to create alpha characters Press a number key then F repeatedly to create alpha characters when needed.	
* Note: The option to Tap the card for various functions will be dependent on the hardware being used and the terminal's configuration for Contact-less processing.	> Address + 0 > Zip Code + 0 Auth Only	Credit Card Force	> Optional Prompts	
Press	Press		 Optional Prompts Optional Prompts may include: 	
Press 3 > Enter the password and press 0 Use Search Menu to locate transaction: 1=All 2=Reference # 3=Clerk # 4=Invoice #/PO # 5=Account # 6=Customer #	Swipe or Key Card and press	Press 4 Select 1 - CREDIT Enter the Sale amount and press Swipe/Tap* or Key Card and press > Enter the expiration date and press Enter Approval Code and press	password, clerk #, invoice/order number, card present, phone order or e-commerce, address, zip, CVC code, pass terminal, enter merchant number for multi-merchant, confirm amt., tax amt., customer code, imprint card, and enter last 4 digits. Not all optional prompts are shown.	
7= RRN 8=Approval Code	> CVC Code, +	Poprint		
S=Approval Code If ALL is selected, use the up/down arrows to scroll through the transactions and press the F4 key to select a transaction to be Voided. Confirm Void \$X.XX? Select Yes or No. Terminal will display VOID response and print a VOID receipt.	 > CVC Code. + > Card present? Choose Yes or No. > Address + > Zip Code + 	Reprint Press 8 Select 3 – REPRINT 8 Select 1 – Last Receipt or 2 - Search 9 Use Search Menu to select transaction to reprint. 1f ALL is selected, use the up/down arrows to scroll through		

Telium Series					
ingenico beyond RETAIL					
Quick Reference Guide					
Debit Sale	Debit Return	Detail Report	Summary Report		
Swipe Card or 1 select 2 - DEBIT Enter the Sale amount and Enter the Sale amount and 0 > If 1 key was pressed, 0 > If 1 key was pressed, 0 > Swipe/Tap Card* > > Confirm Amount? Select Yes or No. > Cash Back? Choose yes or no > Enter Cash back Amount and press 0 > Confirm Amount \$X.XX? 0	Press 2 > Enter the password and press 0 > Select 2 - DEBIT Enter the Return amount and press 0 Swipe or Tap Card* > Confirm Amount \$X.XX? Select Yes or No. Customer will Enter PIN # and press 0	Press	Press		
Select Accept to proceed or Change to Cancel the transaction and begin again.	Credit Trans Adjust	F4 (Next) keys to scroll through transactions. Batch Totals	Settlement		
Customer will Enter PIN # and press	Press Select 1 – TRANS ADJUST Use Search Menu to select transaction to adjust. If ALL is selected, use the up/down arrows to scroll through the transactions and press the F4 key to select a transaction to be Adjusted. Enter new Sale Amount and press	Press	Press 7 Close Batch and Deposit Funds? Select Yes or No.		